適用例

地下外壁



護岸壁



基礎杭



遮水壁



大深度土留壁・止水壁



地下外壁



地中壁施工協会

正会員

[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]

賛助会員

[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]
[illegible]	[illegible]

[illegible]

[illegible]	[illegible]

地中空間に挑む

地中連続壁工法

Diaphragm Wall Method

地中壁施工協会

地中連続壁とは

[illegible]



[illegible]

特長



Diaphragm Wall Method

用途 ●掘削機の選定





[illegible]



バケット式掘削機

[illegible]

[illegible] 掘削機



[illegible] 掘削機

[illegible] 掘削機

[illegible] 掘削機

回転式掘削機

[illegible]

[illegible] 掘削機

[illegible] 掘削機

[illegible] 掘削機



[illegible] 掘削機

施工フロー

[illegible]



先行エレメント施工手順

掘削 → 鉄筋かご建込み → コンクリート打設

後行エレメント施工手順

掘削 → 鉄筋かご建込み → コンクリート打設